

# RM12 ... 16

Analogue Digital Multimeter (User Manual)





- (1) Liquid crystal display
- (2) ON/OFF pushbutton
- (3) Pushbutton for data hold and MIN/MAX storage functions
- (4) Pushbutton for manual range selection
- (5) Multi function pushbutton
- (6) Function selector switch.
- (7) Terminal sockets with automatic blocking system.
- (8) Symbol for"CONTINUOUSLY ON"
- (9) Display for digits ,decimal point and polarity.
- (10) Display for manual range selection, DATA hold and MIN/MAX storage.

- (11) Display for the selected function
- (12) Display for the unit of measured quantity.
- (13) Over range indication for positive analog range.
- (14) Pointer for analog indication.
- (15) Scale for analog indication
- (16) Over range indication for negative analog range.
- (17) Low battery indication.(18) Buzzer indication
- (19) Display <sup>0</sup>C for temperature measurement range.



# 1. Introduction:

Thank you very much for selecting this Multimeter. This handheld multimeters are suitable for use in the fields of general electronics and electrical engineering. These multimeters are manufactured as per DIN43751

# 2. Safety features and safety precautions

You have chosen a multimeter which provides you a very high degree of safety .The analog-digital multimeters RM12 ...16 are

manufactured and tested in compliance with the safety standard DIN VDE 0411and IEC/1010-1 DIN EN/61010-1VDE .0411-1In case of incorrect use or careless handling ,the safety of both user and multimeter is not assured

For proper use and safe handling ,it is absolutely necessary to read and understand the operating instructions before using the meter.

For your safety and for protection of the multimeter ,the RM 12...16 multimeters are fitted with an Automatic terminal Blocking System (ABS). It is coupled with the function selector switch which blocks the terminal sockets not necessary for measurement.

#### Please note the following safety precautions:

- The multimeter must be operated only by persons who understand the danger of shock hazards and are aware of the necessary safety precautions .Shock hazards exist wherever voltages of more than 30V (TRMS) are present.
- Do not work alone in shock hazardous environment while carrying out measurement.
- The maximum permissible voltage between any of the terminal sockets (7) and ground is1000 V. But voltages of more than500 V must be applied only to the unblocked sockets on the voltage measuring ranges (function selector switch (6) set to a" V position")
- Take into account that unexpected voltages can occur on device under test (e.g. defective instrument)For example ,capacitors may be charged to a dangerously high voltage.
- Verify that the test leads are in good condition ,e.g.no cracked insulation ,no open circuits in the leads or connectors.
- This multimeter must not be used for measurements on circuits with corona discharge (high voltage).
- Be particularly careful when measuring on HF circuits .Dangerous composite voltages may exist there.
- Measurements under moist environmental conditions are not permitted.
- All current measuring ranges ,with the exception of the16 A range of RM 13, are protected with fuse. The maximum permissible voltage of the measuring circuit (=nominal voltage of the fuse)is 500V ~ on the "mA" ranges. 600V ~ on the "A" ranges
- You must use the "mA "ranges, 600V ~ on the "A" ranges.
  You must use the "multimeter "only in power systems ,when the current circuit is protected by a fuse or a circuit breaker of20 A ,and when the nominal voltage of the system does not exceed500 V.
- For safe voltage measurements in power systems upto1000 V, we recommend the KS 30measuring adapter ,which is available as an accessory .lts internal resistance limits the measuring current in the case of overvoltage ,in correct operation and safely suppresses sparking from spark gap .Also refer to Section 8.1" Voltage measurement on electrical systems up to1000 V with KS30 measuring adapter.

#### Meaning of the symbols on the device



#### Repair , replacement of parts:

When opening the meter ,live parts may be exposed .Therefore ,the meter must be disconnected from the measuring circuit prior to opening its case for repair or replacement of parts .If repair cannot be avoided unless the meter is opened and live ,this work must only be performed by a gualified person who understands the danger involved.

#### Faults and abnormal stress:

When it is realised that the safe operation is no longer possible ,take the meter out of service and secure it against accidental use. Safe operation may not be possible,

- when the meter shows obvious signs of damage,
- when the meter no longer functions correctly,
- after prolonged storage under adverse conditions,
- due to severe stress during transportation.

#### 3. Switching the multimeter" ON"

#### Battery

We have already fitted your meter with a 9 V flat cell battery according to IEC 6 F 22 or IEC 6 LR .61 It is ready for operation . Before you use the meter for the first time or after storage ,refer to Section 18.1" Maintenance-Battery."

#### Switching the meter" ON"

- Press the" ON/OFF "pushbutton.(2) Switch"-ON "is acknowledged by a sound signal .As long as you
- keep the pushbutton pressed ,all segments of the liquid crystal display (LCD) will appear . The LCD is shown on page.1

After the pushbutton is released ,the meter is ready for operation.

#### Note:

Electric discharges and high-frequency influence may cause incorrect information to be displayed and block the measuring process .Reset the meter by switching it OFF and ON again otherwise ,check the battery connections.

Disconnect the meter from the measuring circuit before you open it ,and see section.18" Maintenance!"

# Automatic TURN-OFF

The meter turns off automatically ,when the measured value remains constant) variations of the measured value  $\geq 2$  +digits (for about10 minutes and when neither a pushbutton nor the function selector switch is operated during that time. It remains ON ,however ,when a current measuring range is selected and a measured value30

#### How to prevent automatic TURN-OFF

In order to prevent automatic" TURN OFF "select" CONTINUOUSLY ON "mode .For this ,press y ellow multi-function pushbutton (5) and the "ON/OFF "pushbutton (2) together .The function" CONTINUOUSLY ON" is shown on the LCD (1) by the symbol  $\int_{ON}$  .(8)

## Turning the multimeter OFF

Press the" ON/OFF "pushbutton.(2)

### 4. Function and range selection

The function selector switch (6) is coupled with the Automatic terminal Blocking System) ABS (which allows access only to two correct sockets for each function .Prior to switching to the "mA "or" A "functions or from the "mA "or" A "functions, remove the test lead from the corresponding socket .When the test leads are plugged-in ,the terminal blocking systems prevents accidental switching to nonpermissible functions.

#### 4.1 Switching the DC current measuring ranges ON "

3 mA for RM12

3 mA and 3 A for RM 13

300 m A 30 ,mA and 3 A for RM14...16

The current measuring ranges mentioned above are not automatically selected when the meter in switched ON .When you need these measuring ranges for your measurements ,you must additionally activate them.

- set the function selector switch (6) to
   (yellow symbol)
- Briefly press the yellow multi-function pushbutton.(5)
   The multimeter acknowledges the start of an offset calibration for these DC current measuring ranges with a sound signal .The digital display (9) of the multimeter shows" CAL "during the calibration procedure.
- Wait for" CAL "to disappear from the display. Thereafter ,the above current measuring ranges are switched" ON." They remain switched-ON until the multimeter turns OFF automatically or is switched OFF manually. Note:
- Automatic turn-OFF is inactive on all current measuring ranges when the measured value display exceeds 30 digits.
   Set the function selector switch (6) to the desired position.

#### 4.2 A utoranging

The multimeters feature autoranging for all measuring ranges with the exception of the 30 mV ---- 300, mV ---- and 10 A ~ ranges .Autoranging is automatically selected after switching the multimeter ON .According to the measured quantity applied ,the multimeter automatically selects the measuring range which gives the best resolution .When switching to frequency measurement and to ratio measurement ,the previously selected voltage measuring range is maintained.

The meter switches automatically to:

the next higher range	at	_+( 3099digits 1 + digit)	
the next lower range		at	_+( 240/280digits 1 - digit)
from the 300mA to the 3mA	range	at	+( 24digits 1 - digit)

provided the 300 mA 30 ,mA and 3 A ranges are not selected according to section4.1

# 4.3 Manual range section

You can switch OFF autoranging and select the ranges manually according to the table on the following page.

Manual mode is switched OFF when pushbutton AUTO/MAN is pressed (4)for approximately1 s ,when the function selector switch (6) is operated, or when the meter is turned OFF and ON again.

When switching back to autoranging from 30 mV  $\cdots$  or 300 mV  $\cdots$  ranges, 3 V  $\cdots$  range is automatically selected.

AUTO/ MAN (4)	Function	Ackn edgei Display	owl- ment Sound Signal
Short	Manual mode on : Used range is fixed	MAN (10)	1 x
Short	$ \begin{array}{lll} & \text{Switching sequence at:} \\ V-:& 3V\rightarrow 30V\rightarrow 300V\rightarrow 1000V\rightarrow 30\ \text{mV}\rightarrow 300\ \text{mV}\rightarrow 30\ \text{mV}\rightarrow 300\ \text{mV}\rightarrow 30\ \text{mV}\rightarrow 300\ \text{m}^{1 2}) \\ & \text{mA} - :300\mu\text{A}^{1 2}\rightarrow 3\text{mA}\rightarrow 300\ \text{mA}^{1}\rightarrow 300\ \text{mA}\rightarrow 300\mu\text{A}^{1 2}) \\ & \text{mA} - :\overline{30^{11}}\rightarrow 30\ \text{mA}^{2}\rightarrow 30\ \text{mA}^{3}\rightarrow 300\ \text{mA}\rightarrow 3\ \text{mA}^{2} \\ & \text{A} - : \ 3A^{11}\rightarrow 10\ \text{A}\rightarrow 3\ \text{A}^{1} \\ & \Omega:  30M\Omega\rightarrow 30\Omega\Omega\rightarrow 30\Omega\Omega\rightarrow 3\ \text{k}\Omega\rightarrow 30\ \text{k}\Omega\rightarrow 300\ \text{k}\Omega\rightarrow 30\ \text{k}\Omega\rightarrow 30\ \text{k}\Omega\rightarrow 300\ \text{k}\Omega\rightarrow 300\ \text{k}\Omega\rightarrow 300\ \text{k}\Omega\rightarrow 30\ \text{k}$	MAN (10)	1 x
Long	Return to autoranging	-	2 x

1) When these measuring ranges are selected

2) except for RM 12/13

3) except for RM 14...16

5. Liquid crystal display

#### 5.1Digital display

The digital display (9) shows the measured value with correct location of decimal point and sign .The selected measuring Unit (12) and the function(11) are simultaneously displayed .When measuring DC quantities ,a minus sign appears in front of the digits ,when the positive pole of the measured quantity is applied to the " $\perp$ " "input terminal .When upper range limit3099 (on the r ange  $\rightarrow$  1999:) ,is exceeded then" OL "is displayed. With V ,A and W measurements, the digital display is updated two times per second.

# 5.2 Analog indication

The analog indication with pointer presentation gives the dynamic response of a moving-coil movement and is updated 20 times per second, when measuring V ,A and W .Analog indication is of particular advantage when observing variations of measured values and for calibration procedures.

The analog indicator has its own polarity indication .When measuring DC quantities ,the analog scale (15) has a negative range of 5 scale

# 6. "DATA"hold facility

The DATA function allows to automatically hold the measured values. This is particularly useful ,for instance ,when connecting the probes to the measuring point requires full attention .When the measured value is applied and the" condition "according to the table shown below is met, the meter holds the measured value on the digital display and emits a sound signal .The probes can now be removed from the measuring point and the measured value on the digital display (9) can be read .When the measured value falls below the limit specified in the table ,the meter is reactivated for a new storage.

The analog indication is not influenced by the DATA hold, The actual measured value can still be noted / read. Note that with a held digital display, the location of the decimal point is also held. With autoranging selected, the measuring range of the analog indicator is no longer known.

	$\downarrow$	Cond	ition	Meterack	knowledgei	ment
Function DATA	DATA MIN/MAX (3)	Measuring Ranges	Limit of Measured Values (digits)	Dis Meas. Value digital	DATA	Sound Signal
Activate	Short				flashes	1 x
Store		$\begin{array}{c} V \simeq {}^{2)} \\ A \simeq {}^{\Omega} \\ F, Hz\%, \end{array}$	280< 24< <sup>3)</sup> >OL 280<	dis- played	dis- played	1 x
Reactive <sup>1)</sup>		$\begin{matrix} V \underline{\sim}^{2^{2}} \\ A \underline{\widetilde{\sim}} \\ \Omega \\ F, Hz\%, \end{matrix}$	280 > 24 > <sup>3)</sup> OL 280 >	stored mea- sured value	flashes	
Reset	Long			Cleared	Cleared	2 x

1) Reactivated by falling below the specified limits of the measured value.

2) With the exception of the ranges 30 mV and 300 mV.

3) 240/280 digits when the ranges 3 mA for RM 12/13 and 300 m A30 , mA 3 ,A for RM 14...16 are selected according to section4.1.

As long as the DATA hold function is active ,manual range selection is not possible .The DATA hold function is switched OFF ,when,

- The" DATA "pushbutton (3) is pressed for approx1 .s .This is acknowledged by 2 sound signals.
- The function selector switch (6) is operated or
- ✓ The multimeter is turned OFF and ON again.

7. Minimum value and Maximum value" MIN/MAX "storage facility. With the MIN/MAX function ,you can hold the minimum and the maximum measured value which was applied to the input of the multimeter after activating MIN/MAX function .The most important application is the determination of the minimum and the maximum value for long-term monitoring of measured quantities .MIN/MAX does not influence the analog indication The actual measured value can still be noted/read. Apply the measured quantity to the meter and select the measuring range prior to activating the MIN/MAX function.

With the function activated ,you can select the measuring ranges only manually ,if you switch to another range ,the stored MIN/MAX values are cleared.

	$\downarrow$			Meterackr	nowledgem	ent
Function MIN/MAX	DATA MIN/MAX (3)	Meas- uring ranges	Measured Values MINandMAX	Dis Meas. Value digital	play MIN MAX	Sound Signal
1. Activate and Store	2 x Short, 30 mV/ 300 mV and <sup>o</sup> C 1 x short	V <b>≃</b> A <sup>Ω</sup> F,Hz% , ℃	Stored	actual meas- ured value	MIN and MAX flash	1 x
2. Store and	↓ short	$V \simeq A \simeq 0$	Storage Continued in the background.	stored MIN value	MIN	1 x
display	short	F,Hz%, ⁰C	new MIN / MAX. values are displayed	stored MAX value	МАХ	1 x
3. Return to.1	↓ Short ↓	Same as.1	Same as,.1 Stored Values are not cleared	same as.1	same as.1	1 x
Reset	Long		Cleared	Cleared	Cleared	2 x

The MIN/MAX function is switched OFF ,when the MIN/MAX pushbutton (3) is pressed for approximately1 s ,or when the function selector switch (6) is operated ,or when the meter is turned OFF and ON again.

#### 8. Voltage measurement

- ✓ According to the voltage to be measured , set the function selector switch (6) to V ,~ V --- or V == .
- Connect the test leads as shown .The" <u>1</u> "socket should be connected to the lowest potential ground available.

#### Notes:

The 30 mV --- and 300 mV --- measuring ranges can only be selected manually with the "AUTO/MAN " pushbutton! (4) On the 1000 V r ange ,an intermittent sound signal warns you ,when the measured value exceeds the upper range limit.

#### Caution:

*Ensure current measuring range ("mA "or" A") is not selected* for voltage measurement ! When the cut-out rating of the fuses is exceeded because of incorrect operation ,a dangerous situation exists.!

# Zero adjustment on the 30 mV 🛛 ---- measuring range

 Connect the test leads to the meter and join the free ends.
 After having selected the measuring range ,briefly press the yellow multifunction pushbutton.(5)

The meter acknowledges zero setting by a sound signal ,the LCD shows "00.00"(1 +digit) and the decimal point flashes .The displayed voltage at the instant the pushbutton is pressed ,is used as reference value (max <u>2</u>00 +digits) it is automatically deducted from the values measured thereafter.

The zero adjustment is cleared when;

- By pressing the yellow multifunction pushbutton (5) for a long time, clearance is acknowledged by the two sound signal.
- By switching the instrument OFF.

#### Voltagemeasurement



Voltagemeasurementonelectricalsystemsupto1000V withtheKS30measuringadapter



# 8.1Voltage measurement on electrical systems up to 1000V with the KS30 measuring adapter.

On low-Voltage systems ,transient overvoltages of several kilovolts can occur due to switching functions or lightning discharges .Direct connection of your multimeter to such systems for voltage measurement can be dangerous.

For voltage measurements in power systems with nominal voltages upto 1000V, use the KS30 measuring adapter. It is an adapter for multimeter which eliminates dangers caused by overvoltages and incorrect operation of the multimeter .It provides the following protective functions..

- Protection of the input circuit of voltage measuring range of multimeters .The internal resistance of the KS 30limits the current in the case of overvoltage.
- Overload capacity : contin uously 1200 Vrms Transient (rise 10 ms/fall 1000 ms)6 kV max.
- Safe suppression of sparking from spark plug after overvoltage.
- Current limitation in the case of incorrect operation (e.g. applying a voltage to a current input)

Voltages above1000 V can be measured with a high-voltage probe, provided the necessary safety precautions are taken!

#### 9. Current Measurement

- First disconnect the power supply to the circuit being measured and/ or to the load ,and discharge all capacitors within that circuit.
- Select the DC current measuring ranges as described in section4.1
- With the function selector switch ,(6) select A ---- for currents300< mA, and mA ---- for currents 300>mA .When measuring current of unknown magnitude , select the highest measuring rangefirst.
- Select the function corresponding to the measured quantity by briefly pressing the yellow multi-function pushbutton .(5) Each time the pushbutton is pressed ,alternate switching takes place between DC and AC on the RM 12...15 or between DC and (DC + AC) on the RM 16. The change-over is acknowledged by a sound signal .The symbols DC and AC (11) are displayed as per selected function on the LCD.

When selecting a range with the function selector switch ,(6) the DC function is always set by default .When pressing the yellow multi-function pushbutton (5) for a long time ,the multimeter always switches back to DC and acknowledges this by two sound signals.

 Connect the multimeter in series with the load ,as shown .Ensure that the connections are tight (without contact resistance).

#### Notes on Current measurement:

- The multimeter must be used only in the power systems ,where the current circuit is protected by a fuse or a circuit breaker of 20 A ,and when the nominal voltage of the system does not exceed500 V.
- Make the measuring circuit connections mechanically strong and secure so that they do not accidentally open .The conductor cross sections and connection points should be designed to avoid excessive heating.
- On the 300 mA and 10 A ranges (16A range for RM 13), an intermittent sound signal warns you ,when the measured value exceeds the upper range limit.
- The current measuring ranges upto 300 mA are protected to a short



#### ACcurrentmeasurementwith)clip-on(currenttransformers



circuit current of 25 A by a fuse 1.6 A 500/V in conjuction ,with power diodes .The cut-out capacity of the fuse is20 kA at a rated voltage of  $500V \sim$  and ohmic load.

 The 3 A and 10 A current measuring ranges are protected by a16 A/ 600V fuse. The cut-out capacity of the fuse is 100 kA at a normal voltage of 600 V ~ and ohmic load.

#### Caution:

The measuring ranges3 A and 16 A of RM 13 are not protected by a fuse!

- A blown fuse is signalled on the LCD the instant a measured quantity having a voltage of more than 4 V is applied to the corresponding connection sockets .Then ,the digital display (9) shows the word "FUSE"
- After a fuse has blown ,eliminate the cause of the overload before using the meter again!
- Replacement of the fuses is described in section .18 " Maintenance."

# 9.1AC current measurement with (clip-on) current transformer

# 9.1.1 Transformer output mA/A

#### Caution:

If current transformers are operated with an open circuit on the secondary side ,e.g. due to defective or disconnected leads ,a blown fuse in the meter ,or a wrong connection ,dangerously high voltages can occur at the connectors .Therefore ,verify that the current circuit of the multimeter and secondary winding of transformer connected to the multimeter forman intact circuit .Connect the transformer to the sockets  $\underline{L}$  and mA and/or A.

The maximum permissible operating voltage is the nominal voltage of the current transformer .When reading the measured value ,take into account the transformer ratio and the additional error in indication.

#### Transformer output RM 12

The RM 12 shows the switching position " $\rightarrow$  A "and the corresponding sockets .Connect to this socket a) clip-on (current transformer with a transmission ratio of ;1000:1 then the measured values are displayed directly in the" A "range.

# 9.1.2 Transformer output V

Many transformers have voltage output (refered as mV/A) The secondary output must therefore be connected to the connection sockets  $\perp$  and V.

# 10. Resistance measurement

- Verify that the device under test is electrically dead .External voltages would falsify the measured result!
- Set the function selector switch (6) to" Ω."
- Connect the device under test as shown.



Forwarddirection

# DiodeTest



ContinuityTest





#### **Zero adjustment on the30** $\Omega$ measuring range

When measuring small resistance values on the 30  $\Omega$  range, you can eliminate the resistance of the leads and contact resistance by zero adjustment.

- Connect the test leads to the multimeter and join the free ends.
- Briefly press the yellow multi-function pushbutton .(5) The meter acknowledges zero adjustment by a sound signal ,the LCD shows "00.00"(1+digit) and the decimal point flashes .The resistance measured at the instant the pushbutton is pressed is used as reference value (max 200.digits) It is automatically deducted from the values measured thereafter .Zero adjustment can be cleared.
- By pressing the yellow multifunction pushbutton (5) for a long time and is acknowledges by two sound signals.
- By switching the multimeter OFF.

#### 11. Diode test and continuity test

- Verify that the device under test is electrically dead .External voltages would falsify the measured results!
- Set the function selector switch (6) to"
- connect the device under test as shown.
- Forward direction and/or short circuit:

The multimeter displays the forward vol tage in Volts .As long as the voltage drop does not exceed the maximum display value of 1.999 V, you can also rest several series-connected elements or reference diodes with small reference voltage.

Reverse direction or open circuit:

The multimeter indicates overrange" OL"

# Note:

Resistors and semiconductor junction in parallel with the diode falsify the measured results!

#### Diode test and continuity test with buzzer

With the" buzzer "function selected ,the meter emits a continuous sound signal on the range...0 approx1 .V.

To switch the buzzer ON:

- Briefly press the yellow multi-function pushbutton.(5)
- The multimeter acknowledges turn-ON with a sound signal .At the same time , the symbol is (18) appears on the LCD.

#### To switch the buzzer OFF

- Briefly press the yellow multi-function pushbutton (5) again.
- The multimeter acknowledges turn-OFF with a sound signal. The

symbol (18) disappears from the LCD.

When selecting the function" Diode test and continuity test "with the function selector switch ,(6) the buzzer is always switched OFF .Repeated brief pressing of the multifunction pushbutton (5) alternately switches the buzzer on and off .When pressing the push button for a long time ,the buzzer is always switched OFF, this is acknowledged by the buzzer sounding twice.

# 12.Capacitance measurement RM 15 and 16

- Verify that the device under test is electrically dead .External voltages would falsify the measured results!
- Set the function selector switch (6) to" F"
- Connect the (discharged!) device under test to the " \_ "and" F" sockets via test lead.

#### Notes:

Connect polarised capacitors with the "—" pole to the"  $\_$  "socket. Resistors and semiconductor junctions in parallel with the capacitor falsify the measured results!

# Zero adjustment on the 30 nF measuring range

When measuring small capacitance values on the 30 nF range ,the internal resistance of the multimeter and the capacitance of the leads can be eliminated by zero adjustment.

- · Connect the test leads to the meter without device under test.
- Briefly press the yellow multi-function pushbutton.(5) The meter acknowledges zero adjustment by a sound signal ,by displaying ""00.00" (1+digit) on the LCD and by a flashing decimal point .The capacitance measured at the instant the pushbutton is pressed is used as reference value (max200.digits) .It is automatically deduced from the values measured thereafter.

The zero adjustment can be cleared

- By pressing the yellow multi-function pushbutton (5) for a long time, clearance is acknowledged by the two sound signal.
- By switching the multimeter off.

# 13. Frequency measurement (RM 15 and 16)

Frequency measurement is possible on all voltage measuring ranges in AC,DC and (AC+DC) modes.

- Set the function selector s witch (6 to V ~ ,V ─ or V ≂
- Connections are made the same way as for voltage measurement, See foot note (8) on page.21
- Briefly press the yellow multi-function pushbutton(5) The multimeter switches to frequency measurement .The frequency is displayed on the LCD.

See section .17" Specifications "for the lowest measurable frequencies and the maximum permissible voltages.

# Changing over between voltage ,frequency and duty cycle measurement

Repeated brief pressing of the yellow multi-function switch (5) changes the measuring functions in the following order:

Voltage  $\rightarrow$  frequency  $\rightarrow$  duty cycle  $\rightarrow$  voltage ....

- From frequency or duty cycle measurement ,directly switching back to voltage measurement is possible.
- by pressing the yellow multi-function pushbutton (5) for a long time. The meter acknowledges this by two sound signals .The voltage measuring range last selected is maintained.
- by operating the function selector switch.(6)

# **14. Duty cycle measurement** (RM 15 and 16) With duty cycle measurement ,we can determine the ratio of pulse duration to cycle time of recurring square-wave signals.

- Set the function selector switch (6) to V ---- or V ==
- Connections are made in the same way as for voltage measurement

Briefly press the yellow multi-function pushbutton (5) twice. The meter switches to duty cycle measurement . The duty cycle-that is the percentage pulse duration of a signal-is displayed on the LCDin%

'	That is:	Duty cycle = (%)	Pulse duration	x100
			Cycle duration	

# Notes:

The applied frequency must remain constant during the duty cycle measurement .Change- over between voltage ,frequency and duty cycle factor measurement is done as described in the preceding section.

#### 15. Temperature measurement

The RM 12...16 allows you to measure temperature with Pt 100and Pt 1000temperature sensors in the range from-  $200 (-100)^{\circ}C850+...^{\circ}C$ .

- Set the function selector switch (6) to" Ω"
- Connect the sensor to the two unblocked terminals.
- Briefly press the yellow multifunction pushbutton.(5) The multimeter switches to temperature measurement ,it automatically detects the connected sensor (Pt 100to Pt1000) and shows the measured temper ature in °C on the digital display.

#### Notes:

This measurement automatically considers the lead resistance of temperature sensors which are available as accessory. It is not possible to switch over to temperature measurement when the 30W 30  $\Omega$  resistance range is selected.

#### Sensor lead resistance up to 50 $\Omega$

Lead resistance of sensors having a value differing from that of sensors can be considered up to a value of 50  $\ \Omega$  as follows:

- Briefly press the yellow multi-function pushbutton (5) again. The LCD now displays the resistance value which the multimeter automatically considers after selecting the temperature measuring range .We can recognise that this is the resistance correction value on the temperature measuring range .The" °C "character is simultaneously shown on the display.
- You can set the lead resistance correction value as follows: Press the DATA--MIN/MAX pushbutton (3) to increment the value ,or the AUTO/MAN pushbutton (4) to decrement the value .Each time the pushbutton is briefly pressed ,the value changes by one digit.
- Briefly press the yellow multi-function pushbutton (5) again. The LCD displays the measured temperature .The flashing decimal point shows you that we have entered a correction value for the lead resistance .The correction value is retained as long as multimeter is switched on.

- Each time the yellow multi-function pushbutton (5) is briefly pressed, the display changes between measured temperature and correction value of the lead resistance.
- We can exit the temperature measurement function
- by pressing the yellow multi-function switch (5) longer ,this is confirmed by the two sound signals.
- by changing the function selector switch.

# Note:

For the lead resistance ,the actual value measured on the digital multimeter should be taken as correction value and not any specified value.

# 16. Computer interface via RS 232C

The RM multimeters are fitted with a serial RS232-C interface for transmission of measured data to computer .The measured values are optically transmitted through the case with infrared light to an interface adapter which is attached to the multimeter .The measured data is passed to the computer via a cable.

# Switching the interface ON

• When switching on the multimeter ,press the "ON/OFF "pushbutton (2) and the " DATA--MIN/MAX "pushbutton (3) together.

With interface switched ON ,automatic turn-OFF of the meter is inactive .This is shown on the LCD (1) by flashing of the (8) symbol. The" DATA " function cannot be activated.

# Interface packs as accessories

# Interface adapter with memory:

By using this adapter it is possible to store the measured data without interfacing the multimeter to the computer .This stored data can be transferred later on to a computer .For establishing a powerful multimeter system you can connect upto ten multimeters offline .Online connection upto six multimeters to the computer is possible via memory adapter.

The interface packs include the adapters ,the necessary connection cables and the " com " 100 data acquisition and evaluation software with operating instructions.

# com 100 software

- The com100 software package corsists of a WINDOWS version. With com ,100 you can simultaneously access ,store ,display and document the measured data of several RM multimeters. The measured values are presented:
- As digital display and analog indication similar to that of the multimeter .(up to 4 multimeters)
- In traces (XY and Yt)as on a-4 channel recorder.
- In tabular form (data logger :upto 10 channels).

The measured data is stored in ASCII format for further processing. For the use of com ,100 the following requirements must be met:

# Software:

• MS WINDOWS 3.0 or higher.

# Hardware:

- IBM compatible PC with 1 MB main memory for the WINDOWS version.
- A VGA or EGA monitor.
- A hard disk with 2 MB free storage space.
- A " 3.5 disk drive for disks with 1.44 MB storage capacity.
- A MICROSOFT- compatible mouse
  If you wish to make hardcopy
  - a printer supported by WINDOWS.

# 17.Specifications

Meas- urement		Meas	uring	Rang	e.		Reso-	Inn	Input impedance				_+( %	Instrinsic of rdg +	error of digita .digits) at ref	al display erence condit	ions	Overl capaci	oad ity(3
Function	RM	12	13	14	15	16	lution	шþ	ut impedant	<i>,</i> <del>,</del> <del>,</del>			12	13	14	15	16	Overload Value	Overload duration
	30.00 mV	•	•	•	•	•	10 mV	10 <	$G\Omega < //40$	pF				0.5 + 3 4)			0.5 + 3 <sup>4)</sup>		
	300.0 mV	٠	•	•	•	•	100 mV	10 <	$G\Omega < //40$	pF	İ			0.5 + 3			0.5 + 3		
	3.000 V	•	•	•	•	•	1 mV	11	M $\Omega$ / 40</td <td>pF</td> <td>İ</td> <td></td> <td></td> <td>0.25 + 1</td> <td></td> <td></td> <td>0.1 + 1</td> <td></td> <td></td>	pF	İ			0.25 + 1			0.1 + 1		
V	30.00 V	٠	•	٠	•	•	10 mV	10	M $\Omega$ / 40</td <td>pF</td> <td>İ</td> <td></td> <td></td> <td>0.25 + 1</td> <td></td> <td></td> <td>0.1 + 1</td> <td></td> <td>Contin-</td>	pF	İ			0.25 + 1			0.1 + 1		Contin-
	300.0 V	٠	•	٠	•	•	100 mV	10 1	$10 \text{ M}\Omega < //40 \text{ pF}$		İ			0.25 + 1			0.1+1	1200 V	uously
	1000 V	٠	•	٠	•	•	1 V	10 1	$M\Omega$ < // 40 p	ρF	İ	0.25 + 1					0.1 + 1	1200 V	
	3.000 V	٠	٠	٠	•	•1)	1mV	111	$M\Omega < //40$ j	ρF				0.75 + 2	)			DC	
V~	30.00 V	٠	٠	٠	•	•1)	10mV	101	$M\Omega < //40$	oF	I			( 300 10D	)igit)		0.75 + 3		
	300.0 V	•	•	•	•	● 1)	100 mV	101	$M\Omega < //40$		ļ			0.75 + 1 ( 300 - Did	nit)		( 10 <digit)< td=""><td>AC</td><td></td></digit)<>	AC	
	1000 V 3.000 V	•	-		-	1)	1 m\/	101	$MO_{1} < //40$	nF			-	( 300 < Di	jii) I -	-		eff/rms	
	30.00 V		-		-	•1)	10 mV	101	$MQ_{\rm e} < //401$	nF			-	-	-	-	0.75 ± 3	sine	
V≂	300.0 V					<ul> <li>1)</li> </ul>	100 mV	101	$MQ_{\rm c} < 1/401$	ηF	-		-	-	-	-	( 10 <digit)< td=""><td>wave</td><td></td></digit)<>	wave	
	1000 V					•1)	1 V	101	$M\Omega < //40$	pF			-	-	-	-	(	Wave	
								Volta	ge drop app	rox.									
								12 S	13 S	14 S / 15S/16 S									
	300.0 μA			٠	•	•	100 nA	-	-	15 mv			-	-	1.0 + 5 (	- > 10 Digit)	0.5 + 5 (> 10 D)		
	3.000 mA	٠	٠	٠	•	•	1 mA	15 mV	15 mv	150 mV	ĺ			) D)	1.0 +	2	0.5 + 2		
Δ	30.00 mA	٠	٠	٠	•	•	10 mA	150 mv	150 mv	650 mV			0.25 + 2	-	1.0 + 5(>	10 Digit)	0.5 + 5 (> 10 D)	0.36 A	5)
	300.0 mA	٠	٠	٠	•	٠	100 mA	1V	1 V	1V				1.0 + 2			0.5 + 2		,
	3.000 A		•	٠	•	•	1 mA	-	100 mV	100 mV	ļ		-	1.0 + 5 (	> 10 Digit)		1.0 +5 (> 10 D)	6)	6)
	10.00 A		16A	•	•	•	10 mA	-	300 mV	270 mV			-	1.0 + 2		40 D: 10	1.0 + 2	•,	-,
	3.000 mA	-		•	•		1 mA	- 150 m\/	- 150 mV	150 mV			-	- Digit)	1.5 + 2(>	10 Digit)	-	0.36 A	5)
A~	30.00 mA	•	•			-	100 mA		11/	-			1.5 + 2(>10	$15\pm 2(>$	- 10 Digit)	-		010071	•,
	10.00 A	-	16A	•		-	10 mA	IV	1V 200 mV	1 V 270 m\/	l		-	1.5 + 2(>		)	-	6)	6)
Δ~	30.00 A <sup>2)</sup>	•	10/1	-	<u> </u>		10 mA	150 mV	-	-			1.5 + 2	-		-			
><	300.0 A <sup>2)</sup>	٠					100 mA	1V			Î		10<)Digit(	-	-	-	-	0.36 A	5)
	3.000 mA					●1)	1 mA	-	-	150 mV			-	-	-	-	1.5 + 4 (> 10 D)		
A≂	300.0 mA					•1)	100 mA	-		1V	Î		-	-	-	-	1.5 + 4 ( > 10 D)	124	5min
	10.00 A					•1)	10 mA	-	-	270 mV	L		-	-	-	-	1.75 + 4(>10D)	127	011111
								No	load volta	ge									
	30.00 Ω	•	•	•	•	•	$10 \text{ m}\Omega$		max .3.2 V					0.5 +	3 4)		0.4 + 3 <sup>4)</sup>	500 V	
	300.0 Ω	•		•			100 mΩ		max .3.2 V		l			0.5 +	+ 3		0.4 + 3	500 V	
Ω	3.000 kW	•					10.0		max 1.25 V					0.4 -	+1		0.2 + 1	DC 10 mi	
	30.00 KVV	•					10.52		max 1.20 V					0.4 +	+		0.2 + 1		10 min
	3 000 MW	•		-		-	1 kO		max 1.25 V				0.4 + 1 0.2 +			0.2 + 1	AC AC		
	30.00 MW	•	•	•	•	•	10 kΩ		max .1.25 V					201	- 1 - 1		0.4 + 1	eff/rms	
->+	2.000 V	٠	•	•	•	•	1 mV		max .3.2 V					0.25	+1		0.1 + 1	wave	

TRMS measurement
 Display with (clip-on)current transformers1 : 1000
 At0 ° ... + 40 °C

4) With zero adjustment ,without zero adjustment 35 + digits

# 5) Continuously

6) RM 13 (Without 16 A fuse!) : 16 A continuously, 20 A 5 min RM 14 ... 16: 12 A 5 min, 16 A 30 s

Meas- urement Func-	leas- Measuring Range ement unc-				Resolution	Discharge Resistance	U <sub>0 max</sub>	 <u>+(</u> %of	Intrinsic reading	error of + .digits	digital display ) at reference c	conditions	Over Capa	load city <sup>3)</sup>			
tion		RM	12	13	14	15	16				12	13	14	15	16	Overload value	Overload duration
		30.00 nF				•	٠	10 pF	250 kΩ	2.5 V	-	-	-	1.0 -	⊦ 3 <sup>4)</sup>	500 V	
		300.0 nF				•	٠	100 pF	250 kΩ	2.5 V	-	-	-	1.0	+ 3	DC / AC	10 min
		3.000 μΦ				•	•	1 nF	25 kΩ	2.5 V	-	-	-	1.0	+ 3	eff / rms	10 min
		30.00 μΦ				•	•	10 nF	25 kΩ	2.5 V	 -	-	-	3.0	+ 3	3110	
									f <sub>min</sub> V <del>····</del>	f <sub>min</sub> V∼							
		300.0 Hz				•		0.1 Hz	1 Hz	45 Hz	-	-	-			3>kHz	
		3.000 kHz						1 Hz	1 Hz	45 Hz	$   0.5 + 1^{7}$		+ 1 <sup>7)</sup>	1200 V continu	continu		
HZ		30.00 kHz						10 Hz	10 Hz	45 Hz	-	-	-	0.0 + 1		_30>kHz;	
		100.0 kHz				•	٠	100 Hz	100 Hz	100 Hz	 -	-	-			300V OUSIY	
%		2.098.0%				•	•	0.1 %	1 Hz		-	-	-	1Hz 1 kHz 1kHz10 kHz;	z _5 +Digit <sup>8)</sup> ±5 Digit/kHz <sup>8)</sup>	<u>1</u> 00>kHz 30 V	
	pt.	200.0- 200.0 +ºC	•	•	•	•	•	0.1 ºC	-	-		2	Kelvin	+ 5 Digit <sup>9)</sup>		500 V	
	100	200.0 + 850.0 +ºC	•	•	•	•	•	0.1 ºC	-		1.0 + 5 <sup>9)</sup>				DC	10 min	
	pt	100.0 - 200.0 +ºC	•	•	•	•	•	0.1 °C	-	-		2	Kelvin	+ 2 Digit <sup>9)</sup>		AC	
	1000	200.0 + 850.0 + <sup>0</sup> C	•	•	•	•	•	0.1 ºC		-			1.0	+ 2 <sup>9)</sup>		sine	

At °C 40 + ... °C

7) Range

3 V  $\simeq$ : U <sub>E</sub> = 1.5 V <sub>eff/rms</sub> ... 100 V <sub>eff/rms</sub>

30 V  $\simeq$ : U<sub>E</sub> = 15 V <sub>eff/rms</sub> ... 300 V <sub>eff/rms</sub>

300V  $\simeq$ : U<sub>E</sub> = 150 V <sub>eff/rms</sub> ... 1000 V <sub>eff/rms</sub>

8) On the range3 V -, square-wave signal positive on one side 15 ... 5 V, f = const ,.not 163.84 Hz or integral multiple.

9) Without sensor.

Measuring voltage for resistance measurement



Voltage U<sub>v</sub> across the resistance R<sub>v</sub> to be measured as a function of measuring range and display.

Measuring current for diode test or continuity test



Measuring current I, as a function of the displayed voltage U across the device under test

Reference conditions

Ambient temperature: 23 +ºC \_2 +K

Relative humidity: 45% ... 55 % RH

Frequency of measured quantity 45Hz ...65 Hz Waveform of the measured quantity sinusoidal

Battery voltage

8 V 0.1 +V

#### Display

Liquid crystal display section (65mm x 30 mm) with analog indication and digital display and with display of the unit of measured quantity ,function and various special functions. Analog: Indication LCD scale with pointer Scale length 55 mm on V --- and A --- 47 ,mm on all other ranges Graduation  $\mp$  5...0...  $\pm$  30 with 35 scale divisions on =, 0...30 with 30 scale divisions on all other ranges Polarity indication with automatic change-over Overrange indication by triangle(13) Sampling rate 20 readings/s ,on  $\Omega$  10 ;readings/s Digital: Display/Height of numer-7 .segment numerals15/mm Number of digits Overrange "OL"is displayed. Polarity indication "-"sign is displayed ,when the positive pole is at" ⊥" Sampling rate 2 reading/s ,on Ω and °C :1 reading/s Power supply 9V flat cell battery ;manganese-dioxide cell according Battery to IEC 6 F ,22 alkaline-manganese cell according to IEC 6 LR 61 or suitable NiCd storage battery. Lifespan With alkaline-manganese cell: approx 750 .hours on V ---- ,A ---approx 200 .hours on V ~, A ~ (12...15) approx 150 .hours on V  $\sim$ , A  $\sim$  (16) When operating with interface :times x0.7 Battery test automatic display of the" ⊣⊢ "symbol ,when the battery voltage drops below approx 7 .V. **Electrical safety** Protection class II according to IEC / 348 DIN VDE 0411 and IEC/1010-1 EN/61010-1VDE0411-1 Overvoltage category Ш Ш 600V Nominal voltage 1000V Contamination degree 2 2 Nominal insulation voltage1000 V according to IEC / 348 DIN VDE0411 Test voltage 6kV~according to IEC 348/DIN VDE0411 EMC Electromagnetic compatibility EN / 50081-1:1992EN 55022:1987class B Emission Immunity EN / 50082-1:1992IEC8 801-2:1991kV AD /IEC3 801-3:1984V/m /IEC0.5 801-4:1988kV Fuses Fuse for upto300 mA ranges Fast blowing 1.6 A500 / V6.3 ;mm X32 mm ;rating20 kA with

500V  $\sim$  and ohmic load; in conjuction with power diodes, protects all current measuring ranges upto300 mA.

#### Fuse for upto10 A ranges

16 A / 600V; 10mm x 38mm; rating 100 kA with 600V ~ and ohmic load ;protects the3 A and10 A ranges upto600 V ;see .18"maintenance "for manufacturers and types of fuses.

# Influence Quantities and Variations

Influence	RangeofInfluence	Measured quantity/	Variation <sup>1)</sup> _+( %of rdg + .digits)				
quantity		Measuring range	1214	15	16		
		30/300 mV	1.	0 + 3	1.0 + 1		
		3 300 V	0.1	5+1	0.1 + 1		
		1000 V <del></del>	0.	2 + 1	0.1 + 1		
		۷ ~	0.	4 + 2	0.3 + 2		
	0°C	0 °C	300 µA²) 300 mA <del></del>	0.	5 + 1	0.15 + 1	
Temperature	21 +°C and	3A / 10 (16) A		0.5 + 1			
	25 +°C 40 +°C	A ~	0.7	75 + 1	0.75+3		
		30 \(\sum 2)	0.0	0.15 + 2	0.15 + 2		
		3K Ω – 3MΩ	0.2	5+1	0.13 + 2		
		30 M Ω	1.	0+1	0.6 + 1		
		30 nF <sup>2)</sup> – 3 µF	•	0.5 -	+ 2		
		30 µF		2.0 -	+ 2		
		Hz	•	0.5 -	+1		
		%	•	_5 +C	Digit		
		– 200 + 200°C		0.5 K + 2			
		850 + 200 +⁰C		0.5 + 2			
.	15 Hz < 30 Hz			-	1.0 + 3		
.	30 Hz < 45 Hz			-	0.5 + 3		
	65 <hz 400hz<="" td=""><td>0.0001/.01</td><td>2.0</td><td>+ 3</td><td>0.5 + 3</td></hz>	0.0001/.01	2.0	+ 3	0.5 + 3		
Frequency	400 <hz 1khz<="" td=""><td>3 300 V ∼</td><td>2.0</td><td>+ 3</td><td>1.0 + 3</td></hz>	3 300 V ∼	2.0	+ 3	1.0 + 3		
of the			•		2.0 + 3		
measured	30 Hz < 45 Hz	1000 V ~	•	•	1.0 + 3		
quantity	65 < Hz 1 kHz	1000 1	- 20	-	0.0 + 3		
'	15 Hz < 30 Hz			- J	10+3		
'	30 Hz < 45 Hz	A ~			0.5+3		
'	65 <hz 1khz<="" td=""><td></td><td>2.0</td><td>3.0 + 3</td></hz>		2.0	3.0 + 3			
	Crest. 1 3	Mar () Aar ()	-	•	_% 1 +of rdg.		
	factor CF 53 <	V~",A~"	-	•	_% 3 +of rdg.		
Wave form of the measured quantity	The permissible crest fac displayed value: Voltage mean CF 5 4 3 2 1 0 0 0 500	tor CF of the AC quanti surement	Current me Current me CF CF CF CF CF CF CF CF CF CF CF CF CF	ed is a function of easurement	of the		

Influence	RangeofInfluence	Measured quantity/	Variation
4 5		Measuring range	1216
		V	_2 +Digit
		٧~	_4 +Digit
		A	_4 +Digit
		A~	_6 +Digit
Battery	⊣Ļ <sup>5)</sup> < 7.9 V 8.1 <v10.0 td="" v<=""><td>30W/ 300 W9C</td><td>_4 +Digit</td></v10.0>	30W/ 300 W9C	_4 +Digit
Vollage		3 kW 30 MΩ	_3 +Digit
		nF μF	_1 +Digit
		Hz	_1 +Digit
		%	_1 +Digit
	75 %	٧≃	
Relative humidity	3 days	A≃ Ω F Hz	1 x intrinsic error
	Meter off	% °C	
DATA	_	_	_1 +Digit
MIN/MAX		V≃.A≃	2 +Digit

1) With temperature : Error data apply per 10 K change in temperature. With frequency : Error data apply to a display from 300 digits onwards.

2) With zero adjustment.

 With unknown waveform(crest factor CF2 < ) ,measure with manual range selection.

4) With the exception of sinusoidal waveform.

5) After the "  $\dashv$  "symbol is displayed.

Influence quantity	RangeofInfluence	Measuring ranges			
Common	Noise quantity max 1000 .V~	٧	120 <db< td=""></db<>		
mode	Noice quantity may 1000 V/m	3V~ 30 ,V~	80 <db< td=""></db<>		
interference	50 Hz 60 Hz sinusoidal	300 V~	70 <db< td=""></db<>		
voltage	00 H2, 00 H2 0H400H44	1000 V~	60 <db< td=""></db<>		
Normal mode interference voltage	Noise quantity V~ valueofthemeasuringrange at atime max 1000 .V~, 50 Hz, 60 Hz. sinusoidal	V	50 <db< td=""></db<>		
	Noise quantity max 1000 .V-	٧~	110 <db< td=""></db<>		

#### Response time (after manual range selection)

Measured quantity/ measuring range	Respon: of analog indication	se time of digital display	Transient response for step function of the measured quantity			
V	0.7 s	1.5 s	from 0 to% 80 of upper range limit			
30W 3 MW	1.5 s	2 s				
30 MW	4s	5 s	from oo to 50 %			
	0.7 s	1.5 s	or upper range limit			
nF μF ,⁰C		max 31 .s				
300 Hz, 3 kHz		max 2 .s	from 0 to% 50			
30, 100 kHz		max 0.7 .s	of upper range limit			
%( 1Hz)		max 9 .s				
%(10 <hz)< td=""><td></td><td>may 2.5 s</td><td>I</td></hz)<>		may 2.5 s	I			

#### Interface

TypeRS232C ,serial ,as per DIN19241Data transmissionOptically with infrared light through the caseBaud rate8192 bits/s

#### Ambient conditions

Functional temperature					
range	10-°C+ 50 °C				
Storage temperature	)				
range	25- °C 70+ °C without batteries				
Climatic class	2z/-10/50/70/75 % with ref erence to VDI/VDE3540				
Altitude	up to 2000 m				

#### Mechanical configuration

Protection type	IP ,50 for the connection sockets IP20	
	according to DIN VDE 0470 Part/ 1 EN60529	
Dimensions	84 mm x 195 mm x 35 mm	
Weight	350 g approx., including battery	

#### 18. Maintenance

Caution

Disconnect the meter from the measuring circuit before you open it to replace the battery or the fuse!

#### 18.1. Battery

Prior to initial start-up ,or after storage of multimeter ,verify that the battery of multimeter does not leak .Repeat this check in regular short intervals. If the battery leaks ,completely remove the battery electrolyte carefully with a moist cloth and install a new battery before you operate multimeter again.

When the symbol"  $\rightarrow \vdash$  (17) "appears on the LCD (1) replace the battery as soon as possible .Measurement can be done ,but a reduced measuring accuracy must be taken into account.

The multimeter operates with a 9 V flat cell battery according to IEC 6 F 22 or IEC 6 LR 61 or with a suitable NiCd storage battery.

#### Replacing the battery

- Place the multimeter on its face ,loosen the two screws on the rear and remove the lower part of the case ,lifting it from the bottom .The lower and the upper part of the case are fixed together at the top on the front by means of wedges.
- Remove the battery from the battery compartment and carefully disconnect battery connectors.
- Snap the battery connectors to a new 9 V battery and insert the battery into the battery compartment.
- Replace the lower part of the case .Start at the top on the front and take care that the wedges are properly engaged at this point.
- Tighten the lower part with the two screws.
   Please destroy the batteries in an environment friendly way.

# 18.2 Fuses

A blown fuse is signalled on the LCD display the instant a measured quantity having a voltage of more than 4 V is applied to the corresponding connection sockets.

Then ,the digital display (9) shows" FUSE"

The 16 A fuse protects the 3 A and 10 A ranges ,the 1.6 A protects all other current measuring ranges .All other measuring ranges continue to function.

When a fuse blows ,first eliminate the cause of the overload before using the multimeter again!

## **Fuse replacement**

Open the multimeter same as for battery replacement

• Remove the blown fuse ,e.g. with the aid of a probe ,and replace it with a new one.

Permissible types

 for current measuring ranges up to 300 mA: Fast blowing fuse type 1.6 A 500 / V 6.3;mm x 32 mm.

# -- for the 3 A and 10 A current measuring ranges:

	туре	Dimensions
Normal fuse	16 A / 600 V~	10 mm x 38 mm

#### Caution:

Absolutely verify that only the specified fuse is installed! If a fuse of other cut-out capacity ,other nominal current or other switching capacity is used ,a dangerous situation exists ,and there is danger of damaging protective diodes ,resistors or other components. The shorting of the fuse holder is not permissible.

#### 18.3 Case

Special maintenance of the case is not required .Take care that the surface between the connection sockets is clean .For cleaning take a moist cloth. Avoid scrabbing.

#### 19. Servicing

When you need service ,please contact:

# ZIEGLER INSTRUMENTS

#### Schnepfenreuther Weg 6, D-90425 Nürnberg, Germany.

TEL. (+49)(911) 38 492 45 FAX. (+49)(911) 32 26 212

2 45E-MAIL212WEBSITE

info@ziegler-instruments.com www.ziegler-instruments.com

made in Germany

